## General Consumables for ALL Kodak Scanners

The consumables listed below are for use with all Kodak Scanners.

Please see individual scanners for consumables and accessories specific to your model.

CAT No.	Description	
853 5981	<i>Kodak Digital Science</i> Roller Cleaning Pads (24 per package) Usage: approximately one pad per day or more frequently if required.	
169 0783	<i>Kodak Digital Science</i> Transport Cleaning Sheets (50 sheets per package) Usage: 2 to 4 sheets per 8-hour shift/machine.	
896 5519	Staticide Wipes / for Kodak Scanners (6 boxes of 24) Usage: approximately 1 per day.	
826 6488	<ul> <li>Brillianize Detailer Wipes / for Kodak Scanners</li> <li>Includes: 12 dual packets with a microfiber cloth</li> <li>Usage: these cleaning pads are an alternative to the Staticide wipes for cleaning and polishing of the scanner's image guides when scanning in color. Do not use this wipes on the feeding or transport rollers.</li> </ul>	
The following parts can be ordered from Parts Service		
TL 2253	Round Cleaning Brush (Natural bristle) – 1 per package	
TL 2156	Flat Cleaning Brush (Natural bristle) – 1 per package	



## Kodak i2400/i2600/i2800 Scanners

CAT No.	Description	
148 4864	<i>Kodak</i> Feed Rollers and Separation Pads for i1200/i1300/SS5XX/i2000 Scanners Includes: 12 tires and 2 pre-separation pads Usage: See the table on page 33 for a guideline on how often to change consumables. These tires are for use on the feed module and separation module.	
173 6115	<i>Kodak</i> Separation Module Includes: 1 separation module Usage: this module has the potential to scan up to 250,000 pages.	
826 9607	<i>Kodak</i> Feed Module Includes: 1 feed module Usage: this module has the potential to scan up to 500,000 pages.	
892 7717	<ul> <li>Kodak White Background Accessory</li> <li>Includes: 1 white background plate.</li> <li>Usage: reduces black background bleed-through, thus producing whiter images. This is an option for the front scanned images only.</li> </ul>	
119 9470	<ul> <li>Kodak Legal Flatbed Accessory</li> <li>Includes: Legal flatbed with white background, 2-meter (6-ft.) USB cable and power supply</li> <li>Usage: for scanning exception documents. Accommodates document sizes up to: legal size 215.9 mm x 355.6 mm (8.5 x 14 in.).</li> </ul>	
818 2271	<i>Kodak</i> A3 Flatbed Accessory for i2000 Series Scanners Includes: A3 Flatbed with black background, 2-meter (6-ft.) USB cable and power supply and Y cable Usage: for scanning exception documents. Accommodates document sizes up to A3 / 302.7 x 420 mm (11.92 x 18.15 in.).	
The following parts can be ordered from Parts Service		
5K0212	Adapter Kit Includes: 2-meter (6-ft.) USB cable and power supply and Y cable Usage: used to connect an existing Kodak A3 Flatbed Accessory or Kodak A4 Flatbed Accessory to a Kodak i2400/i2600/i2800 Scanner.	

## Feed Module and Separator Module Guidelines for the Scan Station 500, s1220 Photo Scanner, PS400/PS800/PS450 Scanners, i2400, i2600, i2800 Scanners and the i100 / i200 / i1200 / i1300 / i1400 Series Scanners Consumables Kits

The following table provides a guideline of how often to change the feed module, separation roller, preseparation pad and tires.

- Feed module and separation roller tires: tire life will vary depending upon paper types, environment and cleanliness. Nominal tire life is approximately 125,000 pages, results will vary. Degradation of feeder performance, multiple feeds, stoppages, etc. indicate a need to change tires. Change all tires on the feed module and separation roller at the same time.
- Feed module and separation roller: it is recommended that you install a new feed module and separation roller approximately every 4<sup>th</sup> tire change. Install a new feed module and separation roller at the same time.
- **Pre-separation pad:** change every other time you change the feed module, separation roller or change the tires.

Feeder Consumables Extra Large Feeder Description Kodak Feed Rollers Kit Consumables Kit CAT No. 148 4864 CAT No. 124 1066 CAT No. 821 5808 Feed Modules (4 tires) 1 5 Separation Rollers (2 tires) 1 5 2 **Pre-Separation Pads** 2 10 Replacement Tires 12 24 120 **Expected scans / kit** 250,000 500,000 2,500,000

NOTE: The replacement tires are for use with the feed module and the separation roller.